

INSTALLATION, OPERATION AND MAINTENANCE MANUAL

Figures 250-DOC and 250-UOC 24" Size Drawing C-1317 Oil-Cushioned Lever & Weight Swing Check Valves

TABLE OF CONTENTS

Introduction	1
Description of Operation	1
Receiving & Storage	1
Installation	1
Valve Construction	2
Start-Up	2
Preventive Maintenance	2
Trouble Shooting	2
Disassembly	2
Assembly	3
Replacement Parts	3
Warranty	3
Parts List	4
Assembly Drawing/Parts Location	4



234 Clay Avenue • Mars, PA 16046 USA
Telephone (724) 776-1020 • Fax (724) 776-1254
E-mail: info-ga@vag-group.com



WARNING: Cancer and Reproductive Harm – www.Prop65Warnings.ca.gov

INSTALLATION, OPERATION and MAINTENANCE

Figures 250-DOC and 250-UOC Oil-Cushioned Lever & Weight Swing Check

INTRODUCTION

This manual will provide the information to properly install, operate and maintain the valve to ensure a long service life. The Figure 250 Swing Check Valve is ruggedly constructed to provide years of trouble-free operation with minimal maintenance.

CAUTION

The valve is NOT recommended for use with toxic or highly corrosive fluids, fuels or fluids containing hazardous gases

The Shop Order (SO) Number, Figure Number, size and pressure rating are stamped on a nameplate attached to the valve. Please refer to the SO number when ordering parts.

DESCRIPTION OF OPERATION

The Figure 250-DOC and 250-UOC Swing Check Valves are an oil-cushioned, counter-weighted rubber-seated check valve designed to permit flow in one direction and close to prevent reverse flow. The valve opens when the inlet pressure exceeds the outlet pressure. The degree of opening depends on the fluid velocity through the valve. The valve will swing closed as fluid velocity decreases and be fully seated before flow reversal precluding slam and bang. The valve employs a hydraulic "shock absorber" as an oil cushion to dampen the valve's rapid closure.

RECEIVING AND STORAGE

Inspect the valve upon receipt for damage during shipment. Carefully unload all valves to the ground without dropping.

The valves should remain in a clean, dry and weather protected area until installed. For long term storage (greater than 6 months) the rubber surfaces of the seat should be coated with a non-toxic lubricant such as "SuperLube" made by Synco Chemical. Do not expose the rubber parts to sunlight or ozone.

INSTALLATION

The "D" in the Figure Number indicates the valve has ANSI Class 125 flanged connections. Figure Numbers with a "U" indicate the valve has ANSI Class 250 flanged connections. An "A" in the Figure

Number (e.g., 250-DAOC, 250-UAOC) indicates the valve is configured for installation in a vertical pipe.

Consult the drawings of record to verify the configuration supplied and installed.

Prior to installation ensure all debris, packing material or other foreign material has been removed from both ports.

The valve can be installed in a horizontal or vertical (upward flow direction) pipe. In either case the counterweight arm must be horizontal when the valve is closed.

Install the valve in the proper flow direction. Forward flow should tend to open the valve.

If installed outdoors, below ground in a vault or in an unheated area, adequate freeze protection must be provided.

Adequate isolating valves should be installed between the valve and the pipeline or system to facilitate maintenance.

Installation immediately downstream of an elbow or a significant increase in pipe size may produce uneven or turbulent flow through the valve and lead to premature wear. Consult factory for recommendations

The valve is not designed to support adjacent equipment, piping loads should not be imposed on the valve and large valves should be properly supported. Ensure mating flanges are square and parallel to the valve flanges before tightening flange bolts.

Flat-faced flanged valves should be mated with flat-faced flanges and full-face gaskets. If ring gaskets are used the bolt material shall be ASTM A307 Grade B (or equivalent). Higher strength bolting should only be used with full-face gaskets.

Lower heavy valves using slings or chains around the valve body and/or the lifting eye. Lubricate the bolts or studs and insert around flange. Lightly tighten bolts until gaps are eliminated. Torque bolts in an alternating pattern in graduated steps. If leakage occurs wait 24 hours and re-torque the bolts but do

not compress the gasket more than 50% or exceed bolt maximum torque rating.

VALVE CONSTRUCTION

The standard Figure 250-DOC and 250-UOC Swing Check Valves have a cast iron body, stainless steel body seat (older valves may have a bronze body seat), stainless steel hinge shaft and cast iron disc with a rubber disc seat. Refer to the List of Materials submitted for the order if non-standard materials were provided.

Refer to Page 4 for details of construction and parts location.

START-UP

The valve generally does not require any calibration or adjustment prior to start-up. The counterweight(s) should be initially placed at the far end of the arm and secured by tightening the set screw (31A).

The valve should smoothly swing open as flow through the valve increases. The amount of opening depends on the flow velocity through the valve and can be observed by watching the external counterweight arm. The valve is "full ported" at about 25 degrees of swing but can swing open as much as 60 degrees.

The oil cushion chamber (shock absorber) will minimize the slam tendency when the valve closes too quickly due to its own counterweight action.

The shock absorber plunger should be adjusted so there is approximately a 1/16" gap between it and the counterweight when the valve is closed.

PREVENTIVE MAINTENANCE

Figure 250-DOC and 250-UOC Swing Check Valves require no scheduled lubrication, adjustment or preventive maintenance.

A monthly inspection should be performed for the first 6 months of operation to ensure the valve is functioning properly and there is no external fluid leakage or audible evidence of water leaking backwards through the closed valve.

Thereafter, a quarterly visual inspection should be performed.

TROUBLESHOOTING

- Shaft packing leakage
Tighten packing gland nuts equally just enough to stop leakage, no more than ½ turn at a time. DO NOT OVER-TIGHTEN!
Replace packing if necessary.
- Leakage past seat when closed
Inspect valve for debris, clean
Inspect seating surfaces for damage, replace as necessary
- Leakage past cover or flange gaskets
Tighten cover or flange bolts
- Disc oscillating when open
Move counterweight(s) toward shaft
- Valve slams upon closing
Move counterweight(s) toward end of arm
Ensure shaft packing is not too tight
Install additional counterweight(s)

WARNING

Removing the valve from the line or disassembling the valve while there is pressure in the valve body may result in injury or damage to the valve

WARNING

Follow all applicable safety regulations and codes and read and understand all instructions before undertaking disassembly.

DISASSEMBLY

All Figure 250-DOC and 250-UOC valves can be serviced while the body remains connected to the pipeline. A skilled technician should perform all work. No special tools are required.

First ensure there is no pressure within the valve and operating equipment is tagged and locked out. Refer to page 4 for parts identification.

It is not necessary to disassemble the entire valve to replace the shaft packing, follow steps 1 to 3. To install packing follow steps 5a and 6a.

1. Ensure there is no pressure within the valve and operating equipment is locked out.
2. Mark the position of the counterweight(s) on the arm. Loosen the counterweight set screw (31A) and slide the weight(s) off the arm. Loosen the counterweight arm set screw (30A) and slide the arm off the shaft, being careful not to lose the key (30E).
3. Loosen and remove the gland stud nuts (16), slide off the gland (15) and remove the gland packing (22).
4. Remove the end plate bolts (35), the end plate (34) being careful not to lose or damage the end plate seal (36) unless it is to be replaced
5. Remove the cover fasteners (10) and lift off the cover (9). If necessary, carefully pry the cover off using a cold chisel between the body and cover. Be careful not to damage

- or lose the cover gasket (8) unless it is to be replaced.
6. Remove the shaft lock pin (18) by threading a screw into the tapped hole.
 7. With the disc and disc arm properly supported, loosen the disc arm set screw (12) and pull the shaft (11) out of the valve. It may be necessary to drive out the shaft from the opposite end.
NOTE: The outer bushing (14) and shaft key (11A) should come out with the shaft. Be careful not to lose the disc arm key. After the shaft is out, remove the inner bushing (13) from the opposite side.
 8. Carefully lift the disc arm assembly out of the body. Remove the disc nut cotter pin (6B), disc nut (6) and disc nut washer (6A).
 9. Remove the seat follower screws (5C), the seat follower (5B) and the renewable seat (5A).
 10. In the unlikely event it's necessary to remove the body seat (2), the spring pins (2A) holding it into the body must be compressed until they no longer "bite" into the body. This is best accomplished by compressing the seat pins (2A) using "vice-grips" and pulling the pins in a radial direction towards the valve centerline.

Inspect all parts for wear and damage. Replace damaged parts.

ASSEMBLY

The valve is reassembled by reversing the disassembly sequence with consideration of the following:

- 1a. Clean and polish all machined bearing and sealing surfaces. Apply a light coat of lubricant to assist in the assembly.
- 2a. Install disc arm key (11A) in the shaft (11) and slide into the body while supporting the disc arm assembly. Ensure the disc arm key slides inside the disc arm.
- 3a. Install the inner bushing (13) and ensure the shaft lock pin (18) has dropped into the groove provided for it on the shaft.
- 4a. Install the outer bushing (14) and lift the disc assembly several times to ensure free closure with no metal-to-metal contact.
- 5a. Install shaft packing (17). Wrap the packing around the shaft and cut on a 45-degree angle, staggering the cuts with each ring. Slide the gland (15) over the shaft and evenly tighten both gland stud nuts (16) to slightly compress the packing. After pressure has been introduced into the valve, re-tighten evenly until leakage stops.
- 6a. Install the shaft end plate (36) with seal (36) and tighten the end plate screws (35) while ensuring the end plate seal (36) remains in the groove provided for it in the end plate

- 7a. Ensure cover gasket sealing surfaces are clean and apply a thin coat of Permatex™ #2 to both surfaces. Tighten cover nuts in an alternating pattern. Re-tighten as needed after pressure has been introduced.
- 8a. Re-install the counterweight arm with key (30E) and tighten counterweight set screw (30A).
- 9a. Slide counterweight(s) (31) onto shaft and lock in place using set screws (31A). Lift counterweight arm and allow it to fall to ensure free movement.
11. Install shock absorber bracket and shock absorber.

REPLACEMENT PARTS

Genuine replacement parts are available from your local VAG/GA Industries representative or from the factory:

VAG USA, LLC
 234 Clay Avenue
 Mars, PA 16046 USA
 Telephone: 724-776-1020
 Fax: 724-776-1254
 E-mail: quotes-ga@vag-group.com

Please have the nameplate data available when ordering parts. Identify needed part(s) by Shop Order (SO) Number, Figure Number, valve size and individual part number.

REPAIR KITS

Soft Goods Kit includes Items 2B, 5A, 8, 17 & 36

Size	Kit Number	Part Number
24"	SW24	2-80-24000-219

Soft Goods AND Disc/Disc Arm Assembly Kit includes above parts plus Items 2B, 3, 3A, 4, 5B, 5C, 6, 6A, 6B, 11A and 12.

Size	Kit Number	Part Number
24"	SW24D	2-80-24000-217

All other parts ordered individually. Consult factor for larger sizes

WARRANTY:

The Warranty for GA Industries valves is included in our Terms and Conditions which can be found here: <https://gaindustries.com/terms>

PARTS LIST

Part No.	Part Name	Std. Material
1	Body	Cast Iron
2	Body Seat Ring	SS (or Bronze)
2A	Seat Pins	Stainless Steel
2B	Seat O-Ring	Rubber
3	Disc	Cast Iron
3A	Disc Center Pin	Steel or SS
4	Disc Arm	Ductile Iron
5A	Renewable Seat	Rubber
5B	Seat Follower	Stainless Steel
5C	Seat Follower Screws	Stainless Steel
6	Disc Nut	Steel or SS
6A	Disc Nut Washer	Steel or SS
6B	Disc Nut Cotter Pin	Stainless Steel
7	Anti-Rotation Pins	Stainless Steel
7A	Anti-Rotation Pin Screws	Stainless Steel
8	Cover Gasket	Composition
9	Cover	Steel
10	Cover Fasteners	Steel or SS
11	Shaft	Stainless Steel
11A	Disc Arm Key	Stainless Steel
12	Disc Arm Set Screw	Stainless Steel
13	Inner Bushing	Bronze

Part No.	Part Name	Std. Material
14	Outer Bushing	Bronze
15	Gland	Cast Iron
16	Gland Stud Nuts	Steel or SS
17	Packing	Teflon
18	Shaft Lock Pin	Brass or SS
30	Counterweight ArmHub	Cast Iron
30E	Counterweight Arm Key	Stainless Steel
30A	C'weight Arm Set Screw	Stainless Steel
30B	C'weight Arm Bolts	Steel
30C	Counterweight Arm	Steel
30D	Counterweight Arm Pins	Steel
31	Counterweight(s)	Cast Iron
31A	Counterweight Set Screw	Stainless Steel
32	Shock Absorber Bracket	Steel
32A	Bracket Screws	Steel
32B	Bracket Pins	Steel
33	Hydraulic Shock Absorber	Commercial
33A	Shock Absorber Bolts	Steel
33B	Shock Absorber Adj. Bolts	Steel
34	Shaft End Plate	Steel
35	End Plate Screws	Steel or SS
36	End Plate Seal	Rubber



