



PARTS LIST

1	Body	10	Cover Bolts	24	Cushion Chamber Bolts	30D	CMT Arm & Lever Key
2	Seat	11	Shaft	25	Cushion Chamber Cover	30E	CMT Arm Pins
2A	Seat Ring Retaining Pin	11A	Disc Arm Key	25A	Chamber Cover Seal	31	Counterweight
2B	Seat Ring Seal	12	Disc Arm Set Screw	25B	Chamber Cover Bolts	31A	CMT Set Screw
3	Disc	14	Outer Bushing	26	Chamber Cover Mt. Sleeve	32	Check Valve
3A	Disc Center Pin	15	Gland	26A	Adjusting Sleeve Locknut	33	Cover Pin
4	Disc Arm	16	Gland Bolts	28	Link	34	Cover Pin
5	Seat Screws	17	Gland Packing	29	Lever	35	Grease Fittings
5A	REMOVABLE SEAT	18	Shaft Pin	29A	Lever Set Screw	35A	ANTI-ROTATION PIN
6	Disc Nut	20	Cushion Chamber	29B	Lever Pin	35B	ANTI-ROTATION PIN
6A	Disc Washer	21	Cushion Chamber Liner	30	CMT Arm Hub Set Screw		
6B	Disc Correr Pin	22	Cushion Chamber Piston	30A	CMT Arm Hub Set Screw		
8	Cover SEAL	22A	Piston Pin Correr Pins	30B	CMT Arm Bolts		
9	Cover	23	Piston Seal	30C	Counterweight Arm		

A		B		C		D		E	
IN	MM	IN	MM	IN	MM	IN	MM	IN	MM
48	1219	28	711	20	508	34	864	33	838
600MM 24"									

GA INDUSTRIES, INC.

600MM (24") SWING CHECK VALVE

Scale: None
 Drawing No. 104285
 Date: 5-30-90
 Rev: 5-30-90